

MT1 Adapter		MT2 Adapter		NK1 Adapter				ER1 Adapter		S11 Adapter
Motorola		Motorola		Nokia				Sony Ericsson		Siemens
250	T189	A835	T730	252*	1260*	3600*	8110**	A2218Z	T200	A35*
260	T8000	C331 T/C	Timeport 270c	260	1261*	3620*	8210*	A2618s	T206	C25*
6188	T8090	C332 T/C	Timeport 280	282*	1610**	3650*	8260*	A2618sc	T226	C35*
Accompli 008	T8097	C333 T/C	V120 (all)	638	2110/SE**	3660*	8265/i*	A2628	T237	C45*
CD920	T8100	C343	V200	909	2260*	3810**	8270*	A2638	T300 (All)	C50*
CD928	T8167	i30 (all)	V270 (all)	918*	2270*	5100*	8290*	A3618	T306	S35*
CD930	T8197	i35 (all)	V280	5110	2285*	5165*	8390*	P800	T310	M46
CD938	T8367	i50 (all)	V300	5120*	3100*	6100*	8860**	P900	T316	S46
L2000	V.BOX	i55 (all)	V400	5125	3110**	6160/i	8890**	R190	T601x	
L2188	V3600	i58	V60 (all)	5160	3200*	6190**	9290*	R300 (All)	T608	
L7082	V3620 (All)	i58/i58sr	V66	5170	3210**	6200*		R310s	T610	
L7089	V3682	i60 (all)	V70	5180	3285*	6225*		R310sc	T616	
M6	V3688	i80 (all)	V600	5185	3300*	6310/i*		R320s	T630	
P6188	V3690	i85 (all)		5191	3310*	6340/i*		R320sc	T637	
P7289	V50	i88 (all)		6110	3360*	636**		R380 (All)	Z200	
P7289i	V51	i90 (all)		6120	3361*	6360*		R520 (All)	Z600	
P7300 (All)	V8088	i95 (all)		6161	3390*	6370*		R600		
P7382i	V8100	i99cl		6162	6510*	6385*		R3001		
P7389	V8160	iDen		6168	3395*	6560*		T20 (All)		
P7688	V8162	im1100		6170	3520*	6585*		T28 (All)*		
P7689		P280		6180	3560*	6590/i*		T29 (All)		
P8000		T270		6185/i*	3570*	6610*		T39		
P8090		T280		6390	3585/i*	6800*		T60 (All)		
P8097		T710 (all)		8250*	3586/i*	7110*		T61 (All)		
P8167		T720 (all)		8810	3588/i*	7160**		T65		
P8767		T721 (all)		8850	3589/i*	7190**		T66		
Startac (All)		T722 (all)		1100*	3590*	7210*		T68 (All)		
		T725		1221*	3595*	7250/i*		T116		

* Require 6V Booster

** Require 9V Booster